

NOISEZERO WV2+ Bluetooth earbuds with enhanced bass. User Guide includes: Pairing Name, Range, True Wireless Configuration, Start Charging, Normal Use, Auto L/R Role Switching, and Factory Reset instructions. Includes diagrams for earbud placement and charging case usage.

INSTRUCTION: HOW TO CORRECTLY WEAR THE EARBUDS:
- Earbuds are designed for a snug fit. Adjust the silicone ear tip (1) to fit the ear canal. (2) Pull the ear back to open the ear canal.
- **NOTE: ALWAYS HOLD THE EDGE (THE THICKNESS EDGE) OF THE EARBUDD WHEN ADJUSTING THE POSITION OF THE EARBUDD.**

FAST TIME SETUP:
1. Turn on Bluetooth on your phone.
2. Press and hold the touch control side of the earbud (earbuds) until the LED (or LED) starts flashing red and blue.
3. Select "PAIR" on the phone's Bluetooth pairing screen.
4. Press and hold the touch control side of the earbud (earbuds) until the LED (or LED) stops flashing and turns solid blue. The earbud (earbuds) is now paired.

REQUIREMENTS (RESET MODE):
1. Press and hold the touch control side of the earbud (earbuds) for 1 sec (until the LED = RED to charge).
2. Then, take out LEFT to POWER ON.
3. Then, take out RIGHT to POWER ON. (Phone is connected).

RESET TO FACTORY DEFAULT:
1. Press and hold the touch control side of the earbud (earbuds) for 10 seconds until the LED (or LED) starts flashing red and blue.
2. Press and hold the touch control side of the earbud (earbuds) for 3 seconds until the LED (or LED) turns solid blue. The earbud (earbuds) is now reset to factory default.